



Svedholm

PLANT

MAINTENANCE INSTRUCTIONS

MAINTENANCE INSTRUCTIONS

Manufacturer

Svedholm Design AB
TEL +46(0) 10 190 20 80

INFO@SVEDHOLM.SE

WWW.SVEDHOLM.SE

Material

Interior fittings in oxidized steel.

Maintenance

Oxidized steel: should be cleaned with a cloth, moistened with water.

Responsibility

Svedholm Design AB is not responsible for damage caused by improper assembly or installation, lack of maintenance, malfunction, neglect/abnormal use or anything else that may be attributed to the user.

Svedholm Design AB, Uppsala